



# **Altius**

# **Climbing Performance**

# **Evaluation System**

Daria Ilina, Deniz Isik, Emirhan Tepebaşı, Mahammad Azizov, Nadia Damianova,  
Oleksandra Sobchyshak, Raisa Rusal, Sofiia Chehrynets






# Introduction



## ***Wearable Sensor Integration***

Altius uses Arduino Nano 33 BLE Rev2-based sensors mounted on each limb to track full body motion during climbing sessions, ensuring detailed data collection




## ***Real-Time analysis and Scoring***

Captured data is streamed live to a central device, where it is analysed to produce a performance score at the end of each session

## ***Objective Metrics for Evaluation***

Key metrics are fall detection, rhythm and flow, smoothness, arm vs leg usage, stability and grip count, offering a robust and data-driven assessment of climbing performance



# ..... System Overview & Components Used ✨

## **System Overview:**

- 4 wearable units (1 per limb)
- Each unit captures **9-axis motion data** (accelerometer, gyroscope, magnetometer)
- Data streamed via **Bluetooth** to a Python-based central
- Performance evaluated via **algorithmic metrics**
- Scores are displayed in **GUI**

## **Hardware:**

- Arduino Nano 33 BLE Rev2
- 7.4V LiPo batteries
- 3D printed cases
- Velcro straps

## **Software:**

- Arduino Firmware (IMU & BLE Communication)
- Python (Data Acquisition & Processing)
- CSV Data Format for Logging Sensor Data










# Arduino setup



- Each Arduino was programmed to send data to the central device using Bluetooth Low Energy (BLE) connection
  - Data was sent as a single 36 byte string (9 values, 4 bytes each)
  - Data was collected by the central device using bleak and asyncio python libraries
  - Data was then logged to 4 .csv files, corresponding to each limb
- 
- 
- 





# Scoring System Overview



## ***Metrics:***

- Rhythm and Fall Detection
  - Arm vs Leg Usage
  - Smoothness
  - Stability
  - Grip Count
- 

**Each metric scores 0–100**



# Fall Detection and Rhythm

**Goal:** Evaluate control, coordination, and timing by detecting falls and assessing movement rhythm throughout the climb

## Fall Detection – How it works:

- Acceleration magnitude is calculated for each limb
- Partial fall: only some limbs exceed  $10 \text{ m/s}^2$
- Full fall: all limbs exceed threshold within 0.5 s
- Identifies moments of lost control

## Rhythm & Flow – How it works:

- Smoothed signals → detect motion vs rest
- Analyze intervals between movements
- “In rhythm” = 1.0–3.0 s between motions

### Algorithm 1 Fall & Rhythm Detection in *ClimbSense*

**Input:** acceleration data for limbs  $\mathcal{L}$ ; thresholds  $t_{fall}, t_{move}$ ; sync window  $\delta$ ; pause  $p$

**Output:** partial falls  $\mathcal{P}$ , full falls  $\mathcal{F}$ , rhythm score  $\mathcal{R}$

```
1: procedure ANALYZECLIMB( $\mathcal{L}, t_{fall}, t_{move}, \delta, p$ )
2:    $\mathcal{P} \leftarrow \emptyset, \mathcal{F} \leftarrow \emptyset, \text{movementTimes} \leftarrow \emptyset$ 
3:   for all limbs  $\ell \in \mathcal{L}$  do
4:     for all frames  $f$  do
5:       compute magnitude  $m = \sqrt{a_x^2 + a_y^2 + a_z^2}$ 
6:       if  $m > t_{fall}$  then
7:         add  $(f.\text{timestamp}, \ell)$  to  $\mathcal{P}$ 
8:       if  $m > t_{move}$  and  $f.\text{timestamp} - \text{lastMoveTime} > p$  then
9:         add  $f.\text{timestamp}$  to  $\text{movementTimes}$ 
10:         $\text{lastMoveTime} \leftarrow f.\text{timestamp}$ 
11:   Group  $\mathcal{P}$  events within window  $\delta$ 
12:   if all limbs triggered within  $\delta$  then
13:     add full fall time to  $\mathcal{F}$ 
14:   sort  $\text{movementTimes}$ 
15:   compute intervals  $\Delta$  between moves
16:    $\mathcal{R} \leftarrow \frac{\text{std}(\Delta)}{\text{mean}(\Delta)}$ 
17:   return  $\mathcal{P}, \mathcal{F}, \mathcal{R}$ 
```



# Arm vs Leg Usage

**Goal:** Evaluate how evenly the climber distributes movement between arms and legs, as an indicator of technique and efficiency

## How it works:

- For each limb, we compute acceleration magnitude from IMU data
- A movement is counted if the change in magnitude exceeds a threshold ( $\theta = 0.8 \text{ m/s}^2$ )
- Total motion events are grouped: Arms vs. Legs

- Ratios are calculated to measure usage balance:

$$\text{Arm Usage Ratio} = \frac{M_{\text{arms}}}{M_{\text{arms}} + M_{\text{legs}}}, \quad \text{Leg Usage Ratio} = \frac{M_{\text{legs}}}{M_{\text{arms}} + M_{\text{legs}}}$$

### *Threshold Interpretation:*

**< 0.3** — Indicates excessive reliance on upper limbs

**0.3–0.6** — Suggests balanced limb usage

**> 0.6** — Reflects effective use of lower limbs, associated with improved endurance



# Smoothness




**Goal:** Measure how calm and steady the climber's movements are

We look at how much acceleration and rotation change - fewer sudden spikes = smoother movement

## How it works:

- Compute magnitude of acceleration and gyroscope:
- A rolling standard deviation detects movement vs. stillness.
- Compute jerk: the rate of change of acceleration and rotation.
- Score Normalization:

$$\text{smoothness score} = \left( 1 - \frac{\text{median jerk}}{\text{max expected jerk}} \right) \cdot 100$$



Score range: **0 (jerky)** to **100 (very smooth)**




# Stability



**Goal:** Evaluate how steady the climber is during static positions (holds), based on sensor stability

## How it works:

- Sensor data is split into short time windows (0.25s)
- A window is "still" if values stay near resting levels
- Sequences of still windows ( $\geq 0.75s$ ) are marked as holds
- Each hold is checked for signal stability (low standard deviation)
- A hold is stable if variation remains below threshold



*Stability Score = proportion of hold windows classified as stable*

**High score** → good control and precise movement

**Low score** → unstable holds, possible hesitation or grip issues





# Grip Count



**Goal:** Count how often the climber holds a grip with each arm — to analyze symmetry and arm usage

## How it works:

- Based on the same “still window” detection as in the Stability metric
- A grip is detected when a still period occurs between two motion phases
- Each arm is tracked independently
- The number of grips per arm is counted across the full climb



→ *Helps identify arm dominance*

→ *Shows if the climber uses both arms symmetrically*


→ *Useful for technique assessment and movement balance*



# Not Smooth Climb

<https://github.com/flaferty/altius/tree/main/videos>


[\*] Scanning for devices...



X

# Arms vs Legs

<https://github.com/flaferty/altius/tree/main/videos>



# Technical Challenges

1

Low data transmission rate

2

A lot of data for threshold tuning

3

Issues with concurrent connection

# Challenges

1

Finding the project idea

2

Choosing the right materials

3

Time management



**Thank you!**

:)

